

DCU



Водовземка с гумичка  
offtake with rubber

пробийте отвор с диаметър 12 mm с арт. FUS - FUT - PNZ  
assembling requires 12 mm hole made with item FUS - FUT - PNZ



code	∅	ЛВ	pack	box	type
IPDCU2000N160 ●	16	<b>0.15</b>	500	3000	B
IPDCU2000N200 ●	20	<b>0.18</b>	500	2500	B

DSU



Водовземка без гумичка  
offtake without rubber

пробийте отвор с диаметър 12 mm с арт. FUS - FUT - PNZ  
assembling requires 12 mm hole made with item FUS - FUT - PNZ



code	∅	ЛВ	pack	box	type
IPDSU5000N160 ●	16	<b>0.14</b>	500	3500	B
IPDSU5000N200 ●	20	<b>0.16</b>	500	3000	B

DRU



Водовземка с гумичка  
offtake with rubber

пробийте отвор с диаметър 17 mm  
assembling requires 17 mm hole



code	∅	ЛВ	pack	box	type
IPDRU2000N160 ●	16	<b>0.35</b>	500	2000	B
IPDRU2000N200 ●	20	<b>0.35</b>	500	1500	B
0EGOP0000170	spare rubber	<b>0.25</b>	500	6000	C

DGU



Водовземка с гумичка  
offtake with rubber

пробийте отвор с диаметър 17 mm  
assembling requires 17 mm hole



code	∅	ЛВ	pack	box	type
IPDGU2000N160 ●	16	<b>0.25</b>	500	2000	B
IPDGU2000N200 ●	20	<b>0.28</b>	500	1500	B
0EGDR8000N000	spare rubber	<b>0.17</b>	500	6000	C

611



Тройник водовземка с гумичка DCU  
tee offtake with rubber DCU

пробийте отвор с диаметър 12 mm с арт. FUS - FUT - PNZ  
assembling requires 12 mm hole made with item FUS - FUT - PNZ



code	∅	ЛВ	pack	box	type
IP6112000N160 ●	16	<b>0.33</b>	100	1600	B

612



Тройник водовземка с гумичка DRU  
tee offtake with rubber DRU

пробийте отвор с диаметър 17 mm  
assembling requires 17 mm hole



code	∅	ЛВ	pack	box	type
IP6122000N160 ●	16	<b>0.57</b>	500	1500	B

613



Тройник водовземка с гумичка DGU  
tee offtake with rubber DGU

пробийте отвор с диаметър 17 mm  
assembling requires 17 mm hole



code	∅	ЛВ	pack	box	type
IP6132000N160 ●	16	<b>0.49</b>	500	1500	B

OLV



Водовземка с гумичка и външна резба  
offtake with rubber with male thread

пробийте отвор с диаметър 12 mm с арт. FUS - FUT - PNZ  
assembling requires 12 mm hole made with item FUS - FUT - PNZ



code	∅	ЛВ	pack	box	type
IPOLV20M0N250 ●	3/4"	<b>0.29</b>	250	2000	B
IPOLV20M0N320	1"	<b>0.42</b>	100	1400	-

TCU



мана за водовземка DCU  
plug for offtake with rubber (dcu)



code	∅	ЛВ	pack	box	type
IPTCU3000N000	-	<b>0.17</b>	500	5000	C

TRU



мана за водовземка DRU  
plug for offtake with rubber (dru)



code	∅	ЛВ	pack	box	type
IPTRU2000N000	-	<b>0.08</b>	500	4000	C

DLF



Водовземка за layflat с резба  
threaded offtake for layflat



code	∅	ЛВ	pack	box	type
IPDLF20D0N25B ●	M/F 3/4" x 1/2"	<b>0.46</b>	50	1000	B
IPDLF50M0N200 ●	M 1/2"	<b>0.46</b>	50	700	B
IPDLF20F0N250 ●	F 3/4"	<b>0.65</b>	50	1000	B

TLF



мана за layflat  
plug for layflat offtake



code	∅	ЛВ	pack	box	type
IPTLF20D0N200 ●	-	<b>0.64</b>	50	700	C

пробийте отвор с диаметър 14 mm с арт. FOR  
assembling requires 14 mm hole made with item FOR